



TEX11 Questions & Answers



TEX11 - The Spray Adhesive

What is TEX11?

TEX11 is a VOC compliant (including California) multi-purpose water white mist spray adhesive & texture prep. See below for texture prep Q&A. TEX11 can be used as a spray adhesive for temporary or permanent bonds wherever you would normally use 3M Super 77™.

Can I install Trim-Tex beads with TEX11?

TEX11 is NOT designed for Trim-Tex bead installation. To install Trim-Tex beads, use our Trim-Tex 847 Spray Adhesive. TEX11 is designed for jobsite and general purpose needs such as: bonding plastics, papers, foams, polyethylene films and housewraps to a variety of surfaces including masonry, metal, glass and all types of wood surfaces. Always test TEX11 in your conditions for your particular use.

How good is TEX11 and how much does it cost?

As shown in the chart to the right TEX11 outperforms 3M 77™ in every category tested. Best of all, TEX11 typically costs 10-20% less than 3M 77™.

| Property | TEX11 | New 3M Super 77 | Comment |
|---|----------|-----------------|--|
| Green Strength (Measures Bond Strength Development @ 15 min.) | 0.88 psi | 0.37 psi | TEX11 develops bond strength more rapidly. |
| Lap Shear Strength | 11.2 psi | 5.7 psi | TEX11 is 96% stronger. |
| Peel Strength | 2.73 pli | 1.35 pli | TEX11 is 102% stronger. |

TEX11 - The Texture Prep

What is a "Texture Prep" and why do I need it?

Not all texture and plaster products are designed equally. Some contain less glue and bonding agents and don't stick too well to untreated beads. TEX11 improves the bond strength of texture and plaster products to metal and plastic beads by as much as 800%.

Which products should I use TEX11 on?

Any bead with a large exposed surface such as Bullnose Beads, Chamfer Beads, Fast Caps and large L Beads. Standard corner beads do not require TEX11.

Is it easy to use?

You bet. After final sanding, spray a light coat of TEX11 on the exposed surface of the bead as shown below. Let the adhesive dry about 30 minutes and the super bonding surface is ready to accept your plaster or texture product.

If TEX11 is similar to 3M Super 77™, can I use 77 as a texture prep?

Sure, but why would you want to? Remember TEX11 gives you superior performance at 10-20% less cost.

How do I clean up unwanted over spray?

Use the Trim-Tex 848 Citrus Cleaner. The 848 Citrus Cleaner is also a great multi-purpose cleaner for a variety of jobsite needs.

I'm sold. Where can I find Trim-Tex TEX11?

TEX11 is sold exclusively through drywall supply yards. Call us at 800-874-2333 for a dealer nearest to you.



NEW PRODUCT FREE SAMPLES ENCLOSED

Note: Samples are in blue cans, shipped product will be in green can shown.



TEX11 Questions & Answers



TEX11 - The Spray Adhesive

What is TEX11?

TEX11 is a VOC compliant (including California) multi-purpose water white mist spray adhesive & texture prep. See below for texture prep Q&A. TEX11 can be used as a spray adhesive for temporary or permanent bonds wherever you would normally use 3M Super 77™.

Can I install Trim-Tex beads with TEX11?

TEX11 is NOT designed for Trim-Tex bead installation. To install Trim-Tex beads, use our Trim-Tex 847 Spray Adhesive. TEX11 is designed for jobsite and general purpose needs such as: bonding plastics, papers, foams, polyethylene films and housewraps to a variety of surfaces including masonry, metal, glass and all types of wood surfaces. Always test TEX11 in your conditions for your particular use.

How good is TEX11 and how much does it cost?

As shown in the chart to the right TEX11 outperforms 3M 77™ in every category tested. Best of all, TEX11 typically costs 10-20% less than 3M 77™.

| Property | TEX11 | New 3M Super 77 | Comment |
|---|----------|-----------------|--|
| Green Strength (Measures Bond Strength Development @ 15 min.) | 0.88 psi | 0.37 psi | TEX11 develops bond strength more rapidly. |
| Lap Shear Strength | 11.2 psi | 5.7 psi | TEX11 is 96% stronger. |
| Peel Strength | 2.73 pli | 1.35 pli | TEX11 is 102% stronger. |

TEX11 - The Texture Prep

What is a "Texture Prep" and why do I need it?

Not all texture and plaster products are designed equally. Some contain less glue and bonding agents and don't stick too well to untreated beads. TEX11 improves the bond strength of texture and plaster products to metal and plastic beads by as much as 800%.

Which products should I use TEX11 on?

Any bead with a large exposed surface such as Bullnose Beads, Chamfer Beads, Fast Caps and large L Beads. Standard corner beads do not require TEX11.

Is it easy to use?

You bet. After final sanding, spray a light coat of TEX11 on the exposed surface of the bead as shown below. Let the adhesive dry about 30 minutes and the super bonding surface is ready to accept your plaster or texture product.

If TEX11 is similar to 3M Super 77™, can I use 77 as a texture prep?

Sure, but why would you want to? Remember TEX11 gives you superior performance at 10-20% less cost.

How do I clean up unwanted over spray?

Use the Trim-Tex 848 Citrus Cleaner. The 848 Citrus Cleaner is also a great multi-purpose cleaner for a variety of jobsite needs.

**1 CASE of TEX11, STOCK # 811 (12 cans per case)
PRICING (1-79 cases) - \$52 That's Only \$4.33 per can
(80 or more) - \$48 That's Only \$4.00 per can**

